

Brugsanvisning

Tillykke med dit nye **Bon-fire®** produkt.

Vi håber, at du vil få stor glæde og mange gode oplevelser med dette nye produkt.

Bon-fire® er udeliv på en ny måde, og vil være med til at samle familie og venner omkring det levende ildsted.

Bon-fire betyder "glædesblus", og det er vort håb at du også vil få denne oplevelse af produktet.

Med venlig hilsen

Bon-fire®

NB! **Bon-fire®** fralægger sig ethvert ansvar ved misbrug af **Bon-fire®** snobrødspind, og det må anbefales at der udvises stor forsigtighed ved brug af **Bon-fire®** snobrødspind sammen med det levende ildsted.

1. De to dele af snobrødspinden skrues sammen.
2. Smør spidsen med lidt olie.
3. Snobrødsdejen vikles rundt om den emaljerede spids på snobrødspinden.
4. Bages over bålet til snobrødet er færdigt, hvorefter det trækkes af pinden.
5. Snobrødspinden tåler ikke overophedning.
6. Rengøres med vand efter brug.
7. Træhåndtaget kan vedligeholdes med træolie.
8. Snobrødspinden må ikke bruges af børn uden opsyn af en voksen. Pas på, da spidsen kan være varm efter brug.

Owners manual

Congratulations with your new **Bon-fire®** product.

We hope you will enjoy many new adventures with this new product.

Bon-fire® is outdoor living in a new way, and will bring family and friends together around the out door fire place.

Bon-fire® means joyful times around the fire, and we hope you will agree with this interpretation.

Best regards

Bon-fire®

NB! **Bon-fire®** disclaims any responsibility in cases of abuse of the **Bon-fire®** twist bread stick, and great caution is recommended whenever using the **Bon-fire®** twist bread stick together with open fire.

1. Assemble the two parts of the twist bread stick.
2. Smear a bit of oil on the tip.
3. Wrap the twist bread dough around the enamel tip of the stick.
4. Bake the twist bread on the fire until the bread is done. Then remove it from the stick.
5. Do not overheat.
6. Rinse with water after use.
7. The wooden handle can be maintained with wood oil.
8. The twist bread stick must not be used by children unattended by a grown-up. Be careful, the tip can be hot after use.

