

SkamoWall Wedge

SkamoWall Wedge is a board, which is used as finishing between wall and ceiling.

- A** Remove loose plaster, tar, paint residues and organic materials. In case of mold growth, clean the wall with a biocidal product.
- B** Make sure that the wall is straight. Several layers of Skamol Adhesive can be applied to straighten up the wall. Each layer should be a maximum thickness of 15mm and must harden before a new layer of adhesive is applied.
- C** Remove dust from the surface of SkamoWall Wedge.
- D** Apply Skamol Adhesive to the wall. Use a notched trowel.
- E** Where necessary, easily cut SkamoWall Wedge to shape. Use ordinary wood-cutting tools.
- F** Mount SkamoWall Wedge. The wedge must be fully glued, and adhesive must be applied to edges adjoining other boards.
- G** Apply Skamol Primer to the surface of the wedge the plaster will be applied.
- H** Approximately 30 minutes after Skamol Primer has been applied, the plaster can be applied to the wedge.
- I** Fill joints, then skim the wall with plaster. Choose between Skamol Smooth Plaster and Skamol Structural Plaster.
- J** When the plaster is hardened, the mounting of SkamoWall is done.

